

SmartCut™
accessories


Swingline®

Straight Blade

Use with SmartCut™ Commercial Trimmers & GBC® A500pro/A510pro A520pro/A530pro Trimmers

To Replace the Blade Assembly:

1. Loosen and remove two knurled knobs.
2. Take off the old blade assembly and replace with a new one.
3. Put knurled knobs back on and tighten.



swingline.com



ACCO Brands
300 Tower Parkway
Lincolnshire, IL 60069-3640
1 800 820 6220
©2007 ACCO Brands

Made to Swingline
Standards in China.

TRM9613RB650K
9613RB•11892•1007



#9613RB