

# SmartCut™ **accessories**

*Swingline®*

## Cutting Mats

Use with SmartCut™  
12" Trimmer:

- Commercial  
and GBC® Trimmer:
- A500pro

Each mat has four  
cutting surfaces.

When a surface is worn,  
rotate mat  
to a new cutting  
surface.

Replace mat when  
all four cutting  
surfaces are worn.

### To Replace the Mat:

1. Slide finger into  
the groove under  
the mat.
2. Loosen the used  
mat and remove.
3. Rotate or replace  
with a new mat.

